




CABINET PARTS

For Model: WED5540SQ0, WED5540ST0
(White) (Biscuit)

29" ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Model: WED5540SQ0, WED5540ST0
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	14	8541401	Spring, Door (2)	33	696144	Strike, Door
	8577188	Installation Instructions	15	3394083	Clip, Front Panel (2)	35	695737	Door, Rear
	W10042960	Sheet, Cycle Feature	16	3392100	Foot, Dryer	36		Door, Front
	8578183	Use & Care Guide		279810	Foot – Optional (Extended Length Package Of 2) (Not Included)		3393549	White
	8528190	Wiring Diagram					3977241	Biscuit
Following May Be Purchased			17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)	37		Handle, Door
DO-IT-YOURSELF REPAIR MANUALS			18		Cabinet		W10095180	White
	677818	Dryer		8530603	White		W10095190	Biscuit
				8530606	Biscuit (Includes Illus. 4)	38	3406129	Seal & Bearing Assembly
2	343641	Screw, 10–16 x 1/2	19	98234	Clip, Ground	39	279393	Terminal Block Kit (For Terminal Block)
3	693995	Screw, Hex Washer Head	20	690363	Lock, Front Top (2)	40	3393008	Screw, 10–16 x 1/2
4	8541400	Bracket, Cabinet	21		Panel, Front	41	3397659	Block, Terminal
5	3396795	Cover, Terminal Block		695620	White	51	8066217	Hinge, Top (2)
6	342043	Screw, 10–32 x 3/8		3977244	Biscuit	53	691366	Idler & Pulley Assembly
7	3396805	Panel, Rear	23	685203	Clip, Felt Pad (3)	56	8066065	Belt, Drive
8	8546676	Clip, Door Spring	24	3389441	Catch, Door Assembly	57	348780	Base, Motor
10	3406107	Door Switch Assembly	26	337189	Clip, Hinge (2)	58	3400500	Bolt, 5/16–18 x 3/4
11	697773	Screw, 6–20 x 7/8	27	694091	Screw, 8–18 x 3/8	59	8066184	Pulley, 60 Hz.
13	3357011	Screw, 10–16 x 1/2	28	8066056	Hinge, R.H.	62	8066206	Motor Assembly 60 Hz.
				8066057	Hinge, L.H.	63	660658	Clamp, Motor
						64	3404162	Clamp, Motor (W/Shield)
						67	3390731	Seal, Door
						68	697776	Screw, 10–32 x 5/8 (External Ground)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: WED5540SQ0, WED5540ST0
(White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS


For Model: WED5540SQ0, WED5540ST0
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console
2	3401684	Wire, Jumper (PTS to Buzzer)
3	694419	Buzzer
4		Cap, End (L.H.)
	8271365	White
	8271368	Biscuit
5	3399639	Switch, Rotary
6	388326	Screw, Console
7	693995	Screw, Hex Head
8		Cap, End (R.H.)
	8271359	White
	8271362	Biscuit
9	3395683	Housing, Connector (Motor)
10		Screen, Lint
	8557857	White
	8557858	Biscuit
11	8536939	Clip, Spring
12	8533971	Screw, 8-18 x 5/16
13	688983	Screw, 8-18 x 5/8
14	8533951	Screw, Grounding
15	8539893	Jumper, (Temp. Switch)
16		Top
	8557930	White
	8557931	Biscuit
17		Knob, Control
	8565944	White
	8565947	Biscuit
18	94614	Terminal
19	3397269	Connector (Timer)
20	3401144	Connector, (PTS Relay)
21	8578906	Timer, 60 Hz.
22	3347243	Connector, 6-Circuit
23	3394427	Clip, Harness
30	357213	Nut, Push-In (2)
32	8299873	Harness, Wiring
33	3398095	Switch, Push-To-Start
34		Timer Knob Assembly
	8566061	White
	8566064	Biscuit
35		Knob, Push-To-Start
	8566073	White
	8566076	Biscuit
36	3936144	Connector
37	8544895	Bracket, Control
38		Panel, Control
	8578852	White
	8578853	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: WED5540SQ0, WED5540ST0
(White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8-18 x 5/8
3	3388703	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8-18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	3387134	Thermostat, Internal-Bias
9	3977393	Thermal Cut-Off (Includes Illus. 15)
10	694089	Wheel, Blower (Includes Illus. 22)
11	8577230	Housing, Blower

Illus. No.	Part No.	DESCRIPTION
12	8066155	Clip
13	343641	Screw, 10-16 x 1/2
14	8541818	Box, Heater
15	3977767	Thermostat, 221°F (105°C)
16	3977373	Bracket, Drum Light
17	8565582	Element, Heater
18	3403634	Socket Assembly
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
20	3406124	Bulb, Light
21	3402841	Lens, Drum Light
23	487909	Screw, 8-15 x 1/2

Illus. No.	Part No.	DESCRIPTION
24	8066086	Drum Hole Plug
25	3390647	Screw, 8-18 x 1/2
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397590	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3403493	Bulkhead
62	692526	Ring, Bearing
63	97787	Screw, 11-16 x 3/4
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: WED5540SQ0, WED5540ST0
(White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

ACCESSORY PARTS

279948 Kit,
Dryer Repair
8522199 Kit, Dryer
Vent Testing
3404351 Dry Rack

PAINT, TOUCH-UP (1/2oz.)

72017 White
4392899 White

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White
4392901 Biscuit
350938 Primer, Gray

PAINT, BULK (1 qt.)

799344 White (Uncut)
4392900 Biscuit (Uncut)